
AdafruitADXL34x Library Documentation

Release 1.0

Bryan Siepert

Jun 07, 2021

Contents

1	Dependencies	3
1.1	Installing from PyPI	3
2	Usage Example	5
3	Contributing	7
4	Documentation	9
5	Table of Contents	11
5.1	Simple test	11
5.2	Motion detection	11
5.3	Freefall detection	12
5.4	Tap detection	13
5.5	adafruit_adxl34x	13
5.5.1	Implementation Notes	13
6	Indices and tables	17
	Python Module Index	19
	Index	21

A CircuitPython driver for the ADXL34x family of accelerometers

This driver depends on:

- [Adafruit CircuitPython](#)
- [Bus Device](#)

Please ensure all dependencies are available on the CircuitPython filesystem. This is easily achieved by downloading the [Adafruit library and driver bundle](#).

1.1 Installing from PyPI

On supported GNU/Linux systems like the Raspberry Pi, you can install the driver locally [from PyPI](#). To install for current user:

```
pip3 install adafruit-circuitpython-adxl34x
```

To install system-wide (this may be required in some cases):

```
sudo pip3 install adafruit-circuitpython-adxl34x
```

To install in a virtual environment in your current project:

```
mkdir project-name && cd project-name
python3 -m venv .env
source .env/bin/activate
pip3 install adafruit-circuitpython-adxl34x
```


CHAPTER 2

Usage Example

```
import time
import board
import adafruit_adxl34x

i2c = board.I2C() # uses board.SCL and board.SDA
accelerometer = adafruit_adxl34x.ADXL345(i2c)

while True:
    print("%f %f %f"%accelerometer.acceleration)
    time.sleep(1)
```


CHAPTER 3

Contributing

Contributions are welcome! Please read our [Code of Conduct](#) before contributing to help this project stay welcoming.

CHAPTER 4

Documentation

For information on building library documentation, please check out [this guide](#).

5.1 Simple test

Ensure your device works with this simple test.

Listing 1: examples/adxl34x_simpletest.py

```
1  # SPDX-FileCopyrightText: 2021 ladyada for Adafruit Industries
2  # SPDX-License-Identifier: MIT
3
4  import time
5  import board
6  import adafruit_adxl34x
7
8  i2c = board.I2C() # uses board.SCL and board.SDA
9
10 # For ADXL343
11 accelerometer = adafruit_adxl34x.ADXL343(i2c)
12 # For ADXL345
13 # accelerometer = adafruit_adxl34x.ADXL345(i2c)
14
15 while True:
16     print("%f %f %f" % accelerometer.acceleration)
17     time.sleep(0.2)
```

5.2 Motion detection

Use the accelerometer to detect motion.

Listing 2: examples/adxl34x_motion_detection_test.py

```
1 # SPDX-FileCopyrightText: 2021 ladyada for Adafruit Industries
2 # SPDX-License-Identifier: MIT
3
4 import time
5 import board
6 import adafruit_adxl34x
7
8 i2c = board.I2C() # uses board.SCL and board.SDA
9
10 # For ADXL343
11 accelerometer = adafruit_adxl34x.ADXL343(i2c)
12 # For ADXL345
13 # accelerometer = adafruit_adxl34x.ADXL345(i2c)
14
15 accelerometer.enable_motion_detection()
16 # alternatively you can specify the threshold when you enable motion detection for
17 # ↪ more control:
18 # accelerometer.enable_motion_detection(threshold=10)
19
20 while True:
21     print("%f %f %f" % accelerometer.acceleration)
22
23     print("Motion detected: %s" % accelerometer.events["motion"])
24     time.sleep(0.5)
```

5.3 Freefall detection

Use the accelerometer to detect when something is dropped.

Listing 3: examples/adxl34x_freefall_detection_test.py

```
1 # SPDX-FileCopyrightText: 2021 ladyada for Adafruit Industries
2 # SPDX-License-Identifier: MIT
3
4 import time
5 import board
6 import adafruit_adxl34x
7
8 i2c = board.I2C() # uses board.SCL and board.SDA
9
10 # For ADXL343
11 accelerometer = adafruit_adxl34x.ADXL343(i2c)
12 # For ADXL345
13 # accelerometer = adafruit_adxl34x.ADXL345(i2c)
14
15 accelerometer.enable_freefall_detection()
16 # alternatively you can specify attributes when you enable freefall detection for
17 # ↪ more control:
18 # accelerometer.enable_freefall_detection(threshold=10,time=25)
19
20 while True:
21     print("%f %f %f" % accelerometer.acceleration)
```

(continues on next page)

(continued from previous page)

```

21
22     print("Dropped: %s" % accelerometer.events["freefall"])
23     time.sleep(0.5)

```

5.4 Tap detection

The accelerometer can also be configured to detect taps.

Listing 4: examples/adxl34x_tap_detection_test.py

```

1  # SPDX-FileCopyrightText: 2021 ladyada for Adafruit Industries
2  # SPDX-License-Identifier: MIT
3
4  import time
5  import board
6  import adafruit_adxl34x
7
8  i2c = board.I2C() # uses board.SCL and board.SDA
9
10 # For ADXL343
11 accelerometer = adafruit_adxl34x.ADXL343(i2c)
12 # For ADXL345
13 # accelerometer = adafruit_adxl34x.ADXL345(i2c)
14
15 accelerometer.enable_tap_detection()
16 # you can also configure the tap detection parameters when you enable tap detection:
17 # accelerometer.enable_tap_detection(tap_count=2, threshold=20, duration=50)
18
19 while True:
20     print("%f %f %f" % accelerometer.acceleration)
21
22     print("Tapped: %s" % accelerometer.events["tap"])
23     time.sleep(0.5)

```

5.5 adafruit_adxl34x

A driver for the ADXL34x 3-axis accelerometer family

- Author(s): Bryan Siepert

Based on drivers by K. Townsend and Tony DiCola

5.5.1 Implementation Notes

Hardware:

- Adafruit ADXL345 Digital Accelerometer (Product ID: 1231)

Software and Dependencies:

- Adafruit CircuitPython firmware for the supported boards: <https://circuitpython.org/downloads>
- Adafruit's Bus Device library: https://github.com/adafruit/Adafruit_CircuitPython_BusDevice

class adafruit_adxl34x.**ADXL343** (*i2c*, *address*=83)
Stub class for the ADXL343 3-axis accelerometer

class adafruit_adxl34x.**ADXL345** (*i2c*, *address*=83)
Driver for the ADXL345 3 axis accelerometer

Parameters

- **i2c** (*I2C*) – The I2C bus the ADXL345 is connected to.
- **address** – The I2C device address for the sensor. Default is 0x53.

Quickstart: Importing and using the device

Here is an example of using the *ADXL345* class. First you will need to import the libraries to use the sensor

```
import board
import adafruit_adxl34x
```

Once this is done you can define your `board.I2C` object and define your sensor object

```
i2c = board.I2C() # uses board.SCL and board.SDA
accelerometer = adafruit_adxl34x.ADXL343(i2c)
```

Now you have access to the *acceleration* attribute

```
acceleration = accelerometer.acceleration
```

acceleration

The x, y, z acceleration values returned in a 3-tuple in m/s^2

data_rate

The data rate of the sensor.

disable_freefall_detection()

Disable freefall detection

disable_motion_detection()

Disable motion detection

disable_tap_detection()

Disable tap detection

enable_freefall_detection (*, *threshold*=10, *time*=25)

Freefall detection parameters:

Parameters

- **threshold** (*int*) – The value that acceleration on all axes must be under to register as dropped. The scale factor is 62.5 mg/LSB.
- **time** (*int*) – The amount of time that acceleration on all axes must be less than *threshold* to register as dropped. The scale factor is 5 ms/LSB. Values between 100 ms and 350 ms (20 to 70) are recommended.

If you wish to set them yourself rather than using the defaults, you must use keyword arguments:

```
accelerometer.enable_freefall_detection(time=30)
```

enable_motion_detection (*, *threshold*=18)

The activity detection parameters.

Parameters `threshold` (*int*) – The value that acceleration on any axis must exceed to register as active. The scale factor is 62.5 mg/LSB.

If you wish to set them yourself rather than using the defaults, you must use keyword arguments:

```
accelerometer.enable_motion_detection(threshold=20)
```

enable_tap_detection (*, *tap_count=1, threshold=20, duration=50, latency=20, window=255*)
The tap detection parameters.

Parameters

- **tap_count** (*int*) – 1 to detect only single taps, and 2 to detect only double taps.
- **threshold** (*int*) – A threshold for the tap detection. The scale factor is 62.5 mg/LSB
The higher the value the less sensitive the detection.
- **duration** (*int*) – This caps the duration of the impulse above `threshold`. Anything above `duration` won't register as a tap. The scale factor is 625 μs/LSB
- **latency** (*int*) – (double tap only) The length of time after the initial impulse falls below `threshold` to start the window looking for a second impulse. The scale factor is 1.25 ms/LSB.
- **window** (*int*) – (double tap only) The length of the window in which to look for a second tap. The scale factor is 1.25 ms/LSB

If you wish to set them yourself rather than using the defaults, you must use keyword arguments:

```
accelerometer.enable_tap_detection(duration=30, threshold=25)
```

events

`events` will return a dictionary with a key for each event type that has been enabled. The possible keys are:

Key	Description
tap	True if a tap was detected recently. Whether it's looking for a single or double tap is determined by the tap param of <code>enable_tap_detection</code>
motion	True if the sensor has seen acceleration above the threshold set with <code>enable_motion_detection</code> .
freefall	True if the sensor was in freefall. Parameters are set when enabled with <code>enable_freefall_detection</code>

range

The measurement range of the sensor.

class `adafruit_adxl34x.DataRate`

An enum-like class representing the possible data rates. Possible values are

- `DataRate.RATE_3200_HZ`
- `DataRate.RATE_1600_HZ`
- `DataRate.RATE_800_HZ`
- `DataRate.RATE_400_HZ`
- `DataRate.RATE_200_HZ`
- `DataRate.RATE_100_HZ`
- `DataRate.RATE_50_HZ`

- `DataRate.RATE_25_HZ`
- `DataRate.RATE_12_5_HZ`
- `DataRate.RATE_6_25HZ`
- `DataRate.RATE_3_13_HZ`
- `DataRate.RATE_1_56_HZ`
- `DataRate.RATE_0_78_HZ`
- `DataRate.RATE_0_39_HZ`
- `DataRate.RATE_0_20_HZ`
- `DataRate.RATE_0_10_HZ`

class `adafruit_adxl34x.Range`

An enum-like class representing the possible measurement ranges in +/- G.

Possible values are

- `Range.RANGE_16_G`
- `Range.RANGE_8_G`
- `Range.RANGE_4_G`
- `Range.RANGE_2_G`

CHAPTER 6

Indices and tables

- [genindex](#)
- [modindex](#)
- [search](#)

a

[adafruit_adxl34x](#), 13

A

acceleration (*adafruit_adxl34x.ADXL345 attribute*), 14
adafruit_adxl34x (*module*), 13
ADXL343 (*class in adafruit_adxl34x*), 13
ADXL345 (*class in adafruit_adxl34x*), 14

D

data_rate (*adafruit_adxl34x.ADXL345 attribute*), 14
DataRate (*class in adafruit_adxl34x*), 15
disable_freefall_detection()
 (*adafruit_adxl34x.ADXL345 method*), 14
disable_motion_detection()
 (*adafruit_adxl34x.ADXL345 method*), 14
disable_tap_detection()
 (*adafruit_adxl34x.ADXL345 method*), 14

E

enable_freefall_detection()
 (*adafruit_adxl34x.ADXL345 method*), 14
enable_motion_detection()
 (*adafruit_adxl34x.ADXL345 method*), 14
enable_tap_detection()
 (*adafruit_adxl34x.ADXL345 method*), 15
events (*adafruit_adxl34x.ADXL345 attribute*), 15

R

range (*adafruit_adxl34x.ADXL345 attribute*), 15
Range (*class in adafruit_adxl34x*), 16