

---

# **AdafruitAM2320 Library Documentation**

***Release 1.0***

**Limor Fried**

**Apr 23, 2020**



---

## Contents

---

<b>1</b>	<b>Dependencies</b>	<b>3</b>
<b>2</b>	<b>Installing from PyPI</b>	<b>5</b>
<b>3</b>	<b>Usage Example</b>	<b>7</b>
<b>4</b>	<b>Contributing</b>	<b>9</b>
<b>5</b>	<b>Documentation</b>	<b>11</b>
<b>6</b>	<b>Table of Contents</b>	<b>13</b>
6.1	Simple test . . . . .	13
6.2	adafruit_am2320 . . . . .	13
6.2.1	Implementation Notes . . . . .	13
<b>7</b>	<b>Indices and tables</b>	<b>15</b>
<b>Python Module Index</b>		<b>17</b>
<b>Index</b>		<b>19</b>



This is a CircuitPython driver for the AM2320 temperature and humidity sensor.



# CHAPTER 1

---

## Dependencies

---

This driver depends on:

- Adafruit CircuitPython

Please ensure all dependencies are available on the CircuitPython filesystem. This is easily achieved by downloading the Adafruit library and driver bundle.



# CHAPTER 2

---

## Installing from PyPI

---

On supported GNU/Linux systems like the Raspberry Pi, you can install the driver locally [from PyPI](#). To install for current user:

```
pip3 install adafruit-circuitpython-am2320
```

To install system-wide (this may be required in some cases):

```
sudo pip3 install adafruit-circuitpython-am2320
```

To install in a virtual environment in your current project:

```
mkdir project-name && cd project-name  
python3 -m venv .env  
source .env/bin/activate  
pip3 install adafruit-circuitpython-am2320
```



# CHAPTER 3

---

## Usage Example

---

See `am2320_simpletest.py` in the examples folder.



# CHAPTER 4

---

## Contributing

---

Contributions are welcome! Please read our [Code of Conduct](#) before contributing to help this project stay welcoming.



# CHAPTER 5

---

## Documentation

---

For information on building library documentation, please check out [this guide](#).



# CHAPTER 6

---

## Table of Contents

---

### 6.1 Simple test

Ensure your device works with this simple test.

Listing 1: examples/am2320\_simpletest.py

```
1 import time
2 import board
3 import busio
4 import adafruit_am2320
5
6 # create the I2C shared bus
7 i2c = busio.I2C(board.SCL, board.SDA)
8 am = adafruit_am2320.AM2320(i2c)
9
10 while True:
11     print("Temperature: ", am.temperature)
12     print("Humidity: ", am.relative_humidity)
13     time.sleep(2)
```

### 6.2 adafruit\_am2320

This is a CircuitPython driver for the AM2320 temperature and humidity sensor.

- Author(s): Limor Fried

#### 6.2.1 Implementation Notes

##### Hardware:

- Adafruit AM2320 Temperature & Humidity Sensor (Product ID: 3721)

### Software and Dependencies:

- Adafruit CircuitPython firmware for the ESP8622 and M0-based boards: <https://github.com/adafruit/circuitpython/releases>
- Adafruit's Bus Device library: [https://github.com/adafruit/Adafruit\\_CircuitPython\\_BusDevice](https://github.com/adafruit/Adafruit_CircuitPython_BusDevice)

```
class adafruit_am2320.AM2320(i2c_bus, address=92)
```

A driver for the AM2320 temperature and humidity sensor.

#### Parameters

- **i2c\_bus** – The `busio.I2C` object to use. This is the only required parameter.
- **address** (`int`) – (optional) The I2C address of the device.

**relative\_humidity**

The measured relative humidity in percent.

**temperature**

The measured temperature in celsius.

# CHAPTER 7

---

## Indices and tables

---

- genindex
- modindex
- search



---

## Python Module Index

---

### a

adafruit\_am2320, 13



---

## Index

---

### A

`adafruit_am2320` (*module*), 13  
`AM2320` (*class in adafruit\_am2320*), 14

### R

`relative_humidity` (*adafruit\_am2320.AM2320 attribute*), 14

### T

`temperature` (*adafruit\_am2320.AM2320 attribute*),  
14