
Adafruit FXAS21002C Library Documentation

Release 1.0

Tony DiCola

Oct 21, 2019

Contents

1	Dependencies	3
2	Installing from PyPI	5
3	Usage Example	7
4	Contributing	9
5	Building locally	11
5.1	Sphinx documentation	11
6	Table of Contents	13
6.1	Simple test	13
6.2	adafruit_fxas21002c	14
6.2.1	Implementation Notes	14
7	Indices and tables	15
	Python Module Index	17
	Index	19

CircuitPython module for the NXP FXAS21002C gyroscope.

CHAPTER 1

Dependencies

This driver depends on:

- [Adafruit CircuitPython](#)
- [Bus Device](#)

Please ensure all dependencies are available on the CircuitPython filesystem. This is easily achieved by downloading the [Adafruit library and driver bundle](#).

CHAPTER 2

Installing from PyPI

On supported GNU/Linux systems like the Raspberry Pi, you can install the driver locally [from PyPI](#). To install for current user:

```
pip3 install adafruit-circuitpython-fxas21002c
```

To install system-wide (this may be required in some cases):

```
sudo pip3 install adafruit-circuitpython-fxas21002c
```

To install in a virtual environment in your current project:

```
mkdir project-name && cd project-name
python3 -m venv .env
source .env/bin/activate
pip3 install adafruit-circuitpython-fxas21002c
```


CHAPTER 3

Usage Example

```
import time
import board
import busio
import adafruit_fxas21002c

i2c = busio.I2C(board.SCL, board.SDA)
sensor = adafruit_fxas21002c.FXAS21002C(i2c)

while True:
    gyro_x, gyro_y, gyro_z = sensor.gyroscope
    print('Gyroscope (radians/s): ({0:0.3f}, {1:0.3f}, {2:0.3f})'.format(gyro_x, ↵
    ↵gyro_y, gyro_z))
    time.sleep(1.0)
```


CHAPTER 4

Contributing

Contributions are welcome! Please read our [Code of Conduct](#) before contributing to help this project stay welcoming.

CHAPTER 5

Building locally

To build this library locally you'll need to install the `circuitpython-build-tools` package.

```
python3 -m venv .env
source .env/bin/activate
pip install circuitpython-build-tools
```

Once installed, make sure you are in the virtual environment:

```
source .env/bin/activate
```

Then run the build:

```
circuitpython-build-bundles --filename_prefix adafruit-circuitpython-fxac21002c --
↳library_location .
```

5.1 Sphinx documentation

Sphinx is used to build the documentation based on rST files and comments in the code. First, install dependencies (feel free to reuse the virtual environment from above):

```
python3 -m venv .env
source .env/bin/activate
pip install Sphinx sphinx-rtd-theme
```

Now, once you have the virtual environment activated:

```
cd docs
sphinx-build -E -W -b html . _build/html
```

This will output the documentation to `docs/_build/html`. Open the `index.html` in your browser to view them. It will also (due to `-W`) error out on any warning like Travis will. This is a good way to locally verify it will pass.

6.1 Simple test

Ensure your device works with this simple test.

Listing 1: examples/fxas21002c_simpletest.py

```
1  # Simple demo of the FXAS21002C gyroscope.
2  # Will print the gyroscope values every second.
3  import time
4
5  import board
6  import busio
7
8  import adafruit_fxas21002c
9
10
11 # Initialize I2C bus and device.
12 i2c = busio.I2C(board.SCL, board.SDA)
13 sensor = adafruit_fxas21002c.FXAS21002C(i2c)
14 # Optionally create the sensor with a different gyroscope range (the
15 # default is 250 DPS, but you can use 500, 1000, or 2000 DPS values):
16 #sensor = adafruit_fxas21002c.FXAS21002C(i2c, gyro_range=adafruit_fxas21002c.GYRO_
    ↳RANGE_500DPS)
17 #sensor = adafruit_fxas21002c.FXAS21002C(i2c, gyro_range=adafruit_fxas21002c.GYRO_
    ↳RANGE_1000DPS)
18 #sensor = adafruit_fxas21002c.FXAS21002C(i2c, gyro_range=adafruit_fxas21002c.GYRO_
    ↳RANGE_2000DPS)
19
20 # Main loop will read the gyroscope values every second and print them out.
21 while True:
22     # Read gyroscope.
23     gyro_x, gyro_y, gyro_z = sensor.gyroscope
24     # Print values.
```

(continues on next page)

(continued from previous page)

```
25     print('Gyroscope (radians/s): ({0:0.3f}, {1:0.3f}, {2:0.3f})'.format(gyro_x, ↵
↵ gyro_y, gyro_z))
26     # Delay for a second.
27     time.sleep(1.0)
```

6.2 adafruit_fxas21002c

CircuitPython module for the NXP FXAS21002C gyroscope. Based on the driver from: https://github.com/adafruit/Adafruit_FXAS21002C

See examples/simpletest.py for a demo of the usage.

- Author(s): Tony DiCola

6.2.1 Implementation Notes

Hardware:

- Adafruit Precision NXP 9-DOF Breakout Board - FXOS8700 + FXAS21002 (Product ID: 3463)

Software and Dependencies:

- Adafruit CircuitPython firmware (2.2.0+) for the ESP8622 and M0-based boards: <https://github.com/adafruit/circuitpython/releases>
- Adafruit's Bus Device library: https://github.com/adafruit/Adafruit_CircuitPython_BusDevice

class adafruit_fxas21002c.**FXAS21002C** (*i2c*, *address=33*, *gyro_range=250*)

Driver for the NXP FXAS21002C gyroscope.

gyroscope

Read the gyroscope value and return its X, Y, Z axis values as a 3-tuple in radians/second.

read_raw()

Read the raw gyroscope readings. Returns a 3-tuple of X, Y, Z axis 16-bit signed values. If you want the gyroscope values in friendly units consider using the gyroscope property!

CHAPTER 7

Indices and tables

- `genindex`
- `modindex`
- `search`

a

`adafruit_fxas21002c`, [14](#)

A

`adafruit_fxas21002c` (*module*), [14](#)

F

`FXAS21002C` (*class in adafruit_fxas21002c*), [14](#)

G

`gyroscope` (*adafruit_fxas21002c.FXAS21002C* *attribute*), [14](#)

R

`read_raw()` (*adafruit_fxas21002c.FXAS21002C* *method*), [14](#)