
Adafruit BME280 Library Documentation

Release 1.0

ladyada

Aug 02, 2018

Contents

1 Installation and Dependencies	3
1.1 Installing from PyPI	3
2 Usage Example	5
3 Contributing	7
4 Building Locally	9
4.1 Sphinx Documentation	9
5 Table of Contents	11
5.1 Simple test	11
5.2 adafruit_bme280 - Adafruit BME680 - Temperature, Humidity, Pressure & Gas Sensor	12
6 Indices and tables	13
Python Module Index	15

I2C and SPI driver for the Bosch BME280 Temperature, Humidity, and Barometric Pressure sensor

CHAPTER 1

Installation and Dependencies

This driver depends on:

- Adafruit CircuitPython
- Bus Device

Please ensure that the driver and all dependencies are available on the CircuitPython filesystem. This can be most easily achieved by downloading and installing the latest Adafruit library and driver bundle on your device.

1.1 Installing from PyPI

On the Raspberry Pi, you can install the driver locally [from PyPI](#). To install system-wide, use:

```
sudo pip3 install adafruit-circuitpython-bme280
```

To install in a virtual environment in your current project:

```
mkdir project-name && cd project-name
python3 -m venv .env
source .env/bin/activate
pip3 install adafruit-circuitpython-bme280
```


CHAPTER 2

Usage Example

```
import board
import digitalio
import busio
import time
import adafruit_bme280

# Create library object using our Bus I2C port
i2c = busio.I2C(board.SCL, board.SDA)
bme280 = adafruit_bme280.Adafruit_BME280_I2C(i2c)

# OR create library object using our Bus SPI port
#spi = busio.SPI(board.SCK, board.MOSI, board.MISO)
#bme_cs = digitalio.DigitalInOut(board.D10)
#bme280 = adafruit_bme280.Adafruit_BME280_SPI(spi, bme_cs)

# change this to match the location's pressure (hPa) at sea level
bme280.sea_level_pressure = 1013.25

while True:
    print("\nTemperature: %0.1f C" % bme280.temperature)
    print("Humidity: %0.1f %%" % bme280.humidity)
    print("Pressure: %0.1f hPa" % bme280.pressure)
    print("Altitude = %0.2f meters" % bme280.altitude)
    time.sleep(2)
```


CHAPTER 3

Contributing

Contributions are welcome! Please read our [Code of Conduct](#) before contributing to help this project stay welcoming.

CHAPTER 4

Building Locally

To build this library locally you'll need to install the `circuitpython-build-tools` package.

```
python3 -m venv .env
source .env/bin/activate
pip3 install circuitpython-build-tools
```

Once installed, make sure you are in the virtual environment:

```
source .env/bin/activate
```

Then run the build:

```
circuitpython-build-bundles --filename_prefix adafruit-circuitpython-veml6070 --
˓→library_location .
```

4.1 Sphinx Documentation

Sphinx is used to build the documentation based on rST files and comments in the code. First, install dependencies (feel free to reuse the virtual environment from above):

```
python3 -m venv .env
source .env/bin/activate
pip3 install Sphinx sphinx-rtd-theme
```

Now, once you have the virtual environment activated:

```
cd docs
sphinx-build -E -W -b html . _build/html
```

This will output the documentation to `docs/_build/html`. Open the `index.html` in your browser to view them. It will also (due to `-W`) error out on any warning like Travis will. This is a good way to locally verify it will pass.

CHAPTER 5

Table of Contents

5.1 Simple test

Ensure your device works with this simple test.

Listing 1: examples/bme280_simpletest.py

```
1 import time
2
3 import board
4 import busio
5 import adafruit_bme280
6
7 # Create library object using our Bus I2C port
8 i2c = busio.I2C(board.SCL, board.SDA)
9 bme280 = adafruit_bme280.Adafruit_BME280_I2C(i2c)
10
11 # OR create library object using our Bus SPI port
12 #spi = busio.SPI(board.SCK, board.MOSI, board.MISO)
13 #bme_cs = digitalio.DigitalInOut(board.D10)
14 #bme280 = adafruit_bme280.Adafruit_BME280_SPI(spi, bme_cs)
15
16 # change this to match the location's pressure (hPa) at sea level
17 bme280.sea_level_pressure = 1013.25
18
19 while True:
20     print("\nTemperature: %0.1f C" % bme280.temperature)
21     print("Humidity: %0.1f %%" % bme280.humidity)
22     print("Pressure: %0.1f hPa" % bme280.pressure)
23     print("Altitude = %0.2f meters" % bme280.altitude)
24     time.sleep(2)
```

5.2 adafruit_bme280 - Adafruit BME680 - Temperature, Humidity, Pressure & Gas Sensor

CircuitPython driver from BME280 Temperature, Humidity and Barometric Pressure sensor

- Author(s): ladyada

```
class adafruit_bme280.Adafruit_BME280
```

Driver from BME280 Temperature, Humidity and Barometric Pressure sensor

altitude

The altitude based on current pressure versus the sea level pressure (`sea_level_pressure`) - which you must enter ahead of time)

humidity

The relative humidity in RH %

pressure

The compensated pressure in hectoPascals.

sea_level_pressure = None

Pressure in hectoPascals at sea level. Used to calibrate `altitude`.

temperature

The compensated temperature in degrees celsius.

```
class adafruit_bme280.Adafruit_BME280_I2C(i2c, address=<sphinx.ext.autodoc.importer._MockObject  
object>)
```

Driver for BME280 connected over I2C

```
class adafruit_bme280.Adafruit_BME280_SPI(spi, cs, baudrate=100000)
```

Driver for BME280 connected over SPI

CHAPTER 6

Indices and tables

- genindex
- modindex
- search

Python Module Index

a

adafruit_bme280, 11

Index

A

Adafruit_BME280 (class in adafruit_bme280), [12](#)
adafruit_bme280 (module), [11](#)
Adafruit_BME280_I2C (class in adafruit_bme280), [12](#)
Adafruit_BME280_SPI (class in adafruit_bme280), [12](#)
altitude (adafruit_bme280.Adafruit_BME280 attribute),
 [12](#)

H

humidity (adafruit_bme280.Adafruit_BME280 attribute),
 [12](#)

P

pressure (adafruit_bme280.Adafruit_BME280 attribute),
 [12](#)

S

sea_level_pressure (adafruit_bme280.Adafruit_BME280 attribute), [12](#)

T

temperature (adafruit_bme280.Adafruit_BME280 attribute), [12](#)