
Adafruit CircuitPython DHT Library Documentation

Release 1.0

Mike McWethy

Mar 20, 2020

Contents

1	Dependencies	3
2	Installing from PyPI	5
3	Usage Example	7
3.1	Hardware Set-up	7
3.2	Basics	7
3.3	Read temperature and humidity	7
4	Contributing	9
5	Documentation	11
6	Table of Contents	13
6.1	Simple test	13
6.2	adafruit_dhtlib	14
7	Indices and tables	15
	Python Module Index	17
	Index	19

CircuitPython support for the DHT11 and DHT22 temperature and humidity devices.

CHAPTER 1

Dependencies

This driver depends on:

- [Adafruit CircuitPython](#)

Please ensure all dependencies are available on the CircuitPython filesystem. This is easily achieved by downloading the [Adafruit library and driver bundle](#).

CHAPTER 2

Installing from PyPI

On supported GNU/Linux systems like the Raspberry Pi, you can install the driver locally [from PyPI](#). To install for current user:

```
pip3 install adafruit-circuitpython-dht
```

To install system-wide (this may be required in some cases):

```
sudo pip3 install adafruit-circuitpython-dht
```

To install in a virtual environment in your current project:

```
mkdir project-name && cd project-name  
python3 -m venv .env  
source .env/bin/activate  
pip3 install adafruit-circuitpython-dht
```


3.1 Hardware Set-up

The DHT11 and DHT22 devices both need a pull-resistor on the data signal wire. This resistor is in the range of 1k to 5k. Please check your device datasheet for the appropriate value.

3.2 Basics

Of course, you must import the library to use it:

```
import adafruit_dht
```

The DHT type devices use single data wire, so import the board pin

```
from board import <pin>
```

Now, to initialize the DHT11 device:

```
dht_device = adafruit_dht.DHT11(<pin>)
```

OR initialize the DHT22 device:

```
dht_device = adafruit_dht.DHT22(<pin>)
```

3.3 Read temperature and humidity

Now get the temperature and humidity values

```
temperature = dht_device.temperature  
humidity = dht_device.humidity
```

These properties may raise an exception if a problem occurs. You should use try/raise logic and catch `RuntimeError` and then retry getting the values after at least 2 seconds. If you try again to get a result within 2 seconds, cached values are returned.

CHAPTER 4

Contributing

Contributions are welcome! Please read our [Code of Conduct](#) before contributing to help this project stay welcoming.

CHAPTER 5

Documentation

For information on building library documentation, please check out [this guide](#).

6.1 Simple test

Ensure your device works with this simple test.

Listing 1: examples/dht_simpletest.py

```
1 import time
2 import board
3 import adafruit_dht
4
5 # Initial the dht device, with data pin connected to:
6 dhtDevice = adafruit_dht.DHT22(board.D18)
7
8 while True:
9     try:
10         # Print the values to the serial port
11         temperature_c = dhtDevice.temperature
12         temperature_f = temperature_c * (9 / 5) + 32
13         humidity = dhtDevice.humidity
14         print(
15             "Temp: {:.1f} F / {:.1f} C   Humidity: {}% ".format(
16                 temperature_f, temperature_c, humidity
17             )
18         )
19
20     except RuntimeError as error:
21         # Errors happen fairly often, DHT's are hard to read, just keep going
22         print(error.args[0])
23
24     time.sleep(2.0)
```

6.2 adafruit_dhtlib

CircuitPython support for the DHT11 and DHT22 temperature and humidity devices.

- Author(s): Mike McWethy

class `adafruit_dht.DHT11` (*pin*)

Support for DHT11 device.

Parameters `pin` (*Pin*) – digital pin used for communication

class `adafruit_dht.DHT22` (*pin*)

Support for DHT22 device.

Parameters `pin` (*Pin*) – digital pin used for communication

class `adafruit_dht.DHTBase` (*dht11*, *pin*, *trig_wait*)

base support for DHT11 and DHT22 devices

humidity

humidity current reading. It makes sure a reading is available

Raises `RuntimeError` exception for checksum failure and for insufficient data returned from the device (try again)

measure ()

measure runs the communications to the DHT11/22 type device. if successful, the class properties temperature and humidity will return the reading returned from the device.

Raises `RuntimeError` exception for checksum failure and for insufficient data returned from the device (try again)

temperature

temperature current reading. It makes sure a reading is available

Raises `RuntimeError` exception for checksum failure and for insufficient data returned from the device (try again)

CHAPTER 7

Indices and tables

- `genindex`
- `modindex`
- `search`

a

adafruit_dht, 13

A

`adafruit_dht` (*module*), 13

D

`DHT11` (*class in adafruit_dht*), 14

`DHT22` (*class in adafruit_dht*), 14

`DHTBase` (*class in adafruit_dht*), 14

H

`humidity` (*adafruit_dht.DHTBase attribute*), 14

M

`measure()` (*adafruit_dht.DHTBase method*), 14

T

`temperature` (*adafruit_dht.DHTBase attribute*), 14