

---

# Adafruitsgp30 Library Documentation

*Release 1.0*

Ladyada

Aug 25, 2018



---

## Contents

---

<b>1</b>	<b>Dependencies</b>	<b>3</b>
<b>2</b>	<b>Usage Notes</b>	<b>5</b>
2.1	Reading from the Sensor . . . . .	5
<b>3</b>	<b>Contributing</b>	<b>7</b>
<b>4</b>	<b>Building locally</b>	<b>9</b>
4.1	Sphinx documentation . . . . .	9
<b>5</b>	<b>Table of Contents</b>	<b>11</b>
5.1	Simple test . . . . .	11
5.2	adafruit_sgp30 . . . . .	12
5.2.1	Implementation Notes . . . . .	12
<b>6</b>	<b>Indices and tables</b>	<b>13</b>
	<b>Python Module Index</b>	<b>15</b>



A CircuitPython driver for the Sensirion SGP30 gas sensor with eCO<sub>2</sub> and TVOC output. This sensor uses I2C!



# CHAPTER 1

---

## Dependencies

---

This driver depends on:

- Adafruit CircuitPython
- Bus Device

Please ensure all dependencies are available on the CircuitPython filesystem. This is easily achieved by downloading the [Adafruit library and driver bundle](#).



# CHAPTER 2

---

## Usage Notes

---

See the guide for wiring and installation instructions.

First, import the library:

```
import busio  
import adafruit_sgp30
```

Next, initialize the I2C bus object:

```
from board import *  
i2c_bus = busio.I2C(board.SCL, board.SDA, frequency=100000)
```

Since we have the I2C bus object, we can now use it to instantiate the SGP30 object:

```
sgp30 = adafruit_sgp30.Adafruit_SGP30(i2c_bus)
```

## 2.1 Reading from the Sensor

To read from the sensor:

```
co2eq, tvoc = sgp30.iaq_measure()  
print("CO2eq = %d ppm \t TVOC = %d ppb" % (co2eq, tvoc))
```



# CHAPTER 3

---

## Contributing

---

Contributions are welcome! Please read our [Code of Conduct](#) before contributing to help this project stay welcoming.



# CHAPTER 4

---

## Building locally

---

To build this library locally you'll need to install the `circuitpython-build-tools` package.

```
python3 -m venv .env
source .env/bin/activate
pip install circuitpython-build-tools
```

Once installed, make sure you are in the virtual environment:

```
source .env/bin/activate
```

Then run the build:

```
circuitpython-build-bundles --filename_prefix adafruit-circuitpython-sgp30 --library_
↪location .
```

## 4.1 Sphinx documentation

Sphinx is used to build the documentation based on rST files and comments in the code. First, install dependencies (feel free to reuse the virtual environment from above):

```
python3 -m venv .env
source .env/bin/activate
pip install Sphinx sphinx-rtd-theme
```

Now, once you have the virtual environment activated:

```
cd docs
sphinx-build -E -W -b html . _build/html
```

This will output the documentation to `docs/_build/html`. Open the `index.html` in your browser to view them. It will also (due to `-W`) error out on any warning like Travis will. This is a good way to locally verify it will pass.



# CHAPTER 5

---

## Table of Contents

---

### 5.1 Simple test

Ensure your device works with this simple test.

Listing 1: examples/sgp30\_simpletest.py

```
1  """ Example for using the SGP30 with CircuitPython and the Adafruit library"""
2
3  import time
4  import board
5  import busio
6  import adafruit_sgp30
7
8  i2c = busio.I2C(board.SCL, board.SDA, frequency=100000)
9
10 # Create library object on our I2C port
11 sgp30 = adafruit_sgp30.Adafruit_SGP30(i2c)
12
13 print("SGP30 serial #", [hex(i) for i in sgp30.serial])
14
15 sgp30.iaq_init()
16 sgp30.set_iaq_baseline(0x8973, 0x8aae)
17
18 elapsed_sec = 0
19
20 while True:
21     print("co2eq = %d ppm \t tvoc = %d ppb" % (sgp30.co2eq, sgp30.tvoc))
22     time.sleep(1)
23     elapsed_sec += 1
24     if elapsed_sec > 10:
25         elapsed_sec = 0
26         print("**** Baseline values: co2eq = 0x%x, tvoc = 0x%x"
27             % (sgp30.baseline_co2eq, sgp30.baseline_tvoc))
```

## 5.2 adafruit\_sgp30

I2C driver for SGP30 Sensirion VoC sensor

- Author(s): ladyada

### 5.2.1 Implementation Notes

#### Hardware:

- Adafruit SGP30 Air Quality Sensor Breakout - VOC and eCO<sub>2</sub> (Product ID: 3709)

#### Software and Dependencies:

- Adafruit CircuitPython firmware for the ESP8622 and M0-based boards: <https://github.com/adafruit/circuitpython/releases>
- Adafruit's Bus Device library: [https://github.com/adafruit/Adafruit\\_CircuitPython\\_BusDevice](https://github.com/adafruit/Adafruit_CircuitPython_BusDevice)

```
class adafruit_sgp30.Adafruit_SGP30(i2c, address=88)
```

A driver for the SGP30 gas sensor.

**baseline\_co2eq**

Carbon Dioxide Equivalent baseline value

**baseline\_tvoc**

Total Volatile Organic Compound baseline value

**co2eq**

Carbon Dioxide Equivalent in parts per million

**get\_iaq\_baseline()**

Retreive the IAQ algorithm baseline for CO2eq and TVOC

**iaq\_init()**

Initialize the IAQ algorithm

**iaq\_measure()**

Measure the CO2eq and TVOC

**set\_iaq\_baseline(co2eq, tvoc)**

Set the previously recorded IAQ algorithm baseline for CO2eq and TVOC

**tvoc**

Total Volatile Organic Compound in parts per billion.

# CHAPTER 6

---

## Indices and tables

---

- genindex
- modindex
- search



---

## Python Module Index

---

a

adafruit\_sgp30, [11](#)



---

## Index

---

### A

Adafruit\_SGP30 (class in adafruit\_sgp30), [12](#)  
adafruit\_sgp30 (module), [11](#)

### B

baseline\_co2eq (adafruit\_sgp30.Adafruit\_SGP30 attribute), [12](#)  
baseline\_tvoc (adafruit\_sgp30.Adafruit\_SGP30 attribute), [12](#)

### C

co2eq (adafruit\_sgp30.Adafruit\_SGP30 attribute), [12](#)

### G

get\_iaq\_baseline() (adafruit\_sgp30.Adafruit\_SGP30 method), [12](#)

### I

iaq\_init() (adafruit\_sgp30.Adafruit\_SGP30 method), [12](#)  
iaq\_measure() (adafruit\_sgp30.Adafruit\_SGP30 method), [12](#)

### S

set\_iaq\_baseline() (adafruit\_sgp30.Adafruit\_SGP30 method), [12](#)

### T

tvoc (adafruit\_sgp30.Adafruit\_SGP30 attribute), [12](#)